

## INSTALLATION OF THE LONG SIDE WALL TO AWNING ROLLER

1. Open the roll out awning following manufacturer's instructions.
2. On the top of the long side wall there is a PVC wrapped rope edge that is used to hang the wall from the roll out awning.
3. Locate the empty channel/grove on the canister of the roll out awning and have this sitting at the 3 o'clock/9 o'clock position. Carefully slide the PVC rope edge of the wall through this channel.
4. Peg/rope down as desired.

## INSTALLATION OF FRONT/BACK WALL USING AN ANTI FLAP KIT

1. Open the roll out awning following manufacturer's instructions.
2. Locate the empty channel/grove on the canister of the roll out awning and have this sitting at the 3 o'clock/9 o'clock position.
3. Fit the Anti Flap Kit following manufacturer's instructions.
4. Slide the Austral Sun Shade end wall into the rope track of the Anti Flap Kit. Start from the gap in the middle of the Anti Flap Kit and slide the wall towards the caravan and then starting from the middle again slide the shade towards to canister of the Rollout Awning.
5. Peg/rope down as desired.